

Wallace Island Slough - NW end (OR)**LCR-48.1M**

Position - Location: 46° 8.436', -123° 16.569' 46° 8' 26.2", -123° 16' 34.2" 46.14060, -123.27616 Westport

Strategy Objective: Exclusion : Keep oil out of sloughs during high flow conditions.

Implementation: Deploy only at high water. Launch workboat with 600ft. boom and shallow-water skiff from Westport boat launch, BL-LCR-43.8L. Deploy boom across the north entrance to the slough on the west end of Wallace Island. Using a shallow water skiff, anchor to AP-1 and AP-2 using shoreside anchors or natural anchor points. Anchor along boom length every 100-150ft. or as necessary for conditions.


Staging Area: Remote: Stage at Westport boat ramp, SA-LCR-43.8L. Launch from same BL-LCR-43.8L.

Site Safety: Very shallow water, slips, trips, falls, water hazard

Field Notes: Boat access only. Water depth is likely to be very shallow. When the river is low, booming will likely not be necessary or feasible.

Watercourse: Slough - Wallace Island Slough

Resources at Risk: Mudflat Habitat, Waterfowl, Whitetail Deer Habitat

**Recommended Equipment**

5	Each	Anchor - Danforth (or other appropriate type)
2	Each	Anchoring System(s)- Shoreside
600	Feet	Boom - B3 (Contractor Boom) or equivalent
1	Each	Workboat(s) - of adequate size for type and amount of boom
1	Each	Workboat(s) - (jon boat)

Recommended Personnel

2	Boat Operator
2	Laborer
1	Supervisor