

**Walker Island (OR)****LCR-59.8L**

**Position - Location:** 46° 9.077', -123° 3.743' 46° 9' 4.6", -123° 3' 44.6" 46.15128, -123.06239 Longview

**Strategy Objective:** Collection : Prevent oil from moving up channel behind island.

**Implementation:** Launch workboat from BL-LCR-57.8R, Willow Grove boat launch, with 600 ft. boom. Deploy boom at downstream angle to collect oil moving upstream with tide or wind. Anchor to AP-1 using natural anchors or shoreside anchor posts and to AP-2 using Danforth or other anchor. Anchor every 100-150ft. along boom length or as necessary for conditions. Collect oil on water using portable skimmer and storage.

**Staging Area:** Remote: Stage at SA-LCR-57.8R, Willow Grove County Park

**Site Safety:** Slips, Trips, Falls, Water Hazard, & Active Railroad, expect trains on the track at any time/from either direction.

**Field Notes:** Boat access only. At 30 feet from shore water is about 25 feet deep. Do not allow people/equipment within 25' of railroad tracks.

**Watercourse:** River - With Tidal Influence - Columbia River

**Resources at Risk:** Downstream Resources

**Recommended Equipment**

5	Each	Anchor - Danforth (or other appropriate type)
1	Each	Anchoring System(s)- Shoreside
600	Feet	Boom - B2 (Contractor Boom) or equivalent
1	Each	Skimmer (appropriately sized) with Portable Storage
1	Each	Workboat(s) - of adequate size for type and amount of boom

**Recommended Personnel**

1	Boat Operator
2	Laborer
1	Supervisor