



TIRE PRESSURE WARNING RECEIVER


COMPONENTS

for Double Cab:




TW

for Double Cab:




N*m (kgf*cm, ft*lb) : Specified torque

for Double Cab:




w/ Woofer:




TW


for Regular Cab on Separate Seat Type:



for Regular Cab on Bench Seat Type:




for Access Cab:




TW

for Double Cab:



for Regular Cab:




$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

H

B087473E04


TW

for Access Cab:



$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

for Double Cab:




$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

H


B087409E03

TW

for Regular Cab:




for Bench Seat Type:



N*m (kgf*cm, ft*lb) : Specified torque

for Access Cab:





N*m (kgf*cm, ft*lb) : Specified torque

H


B087434E03

TW

for Double Cab:




for Regular Cab:





TW

for Access Cab:



w/ EC Mirror:





N*m (kgf*cm, ft*lbf) : Specified torque