



# ROOF HEADLINING (for Regular Cab)


## COMPONENTS

for Separate Seat Type:



for Bench Seat Type:







IR

$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

IR




for Bench Seat Type:




N\*m (kgf\*cm, ft\*lb) : Specified torque

for Separate Seat Type:




for Manual Transmission:





for Bench Seat Type:

for Automatic Transmission:




for Manual Transmission:





**for Pedal Type Parking Brake:**




**for Lever Type Parking Brake:**




**N\*m (kgf\*cm, ft\*lbf)** : Specified torque

IR



N\*m (kgf\*cm, ft\*lbf) : Specified torque



● Non-reusable part