



ENGINE ASSEMBLY


COMPONENTS





N*m (kgf*cm, ft*lbf) : Specified torque


EM



N*m (kgf*cm, ft*lbf) : Specified torque ← MP grease


Y

2WD AND PRE RUNNER, MANUAL TRANSMISSION:




EM

4WD, MANUAL TRANSMISSION:




4WD, MANUAL TRANSMISSION:




EM


4WD, MANUALTRANSMISSION:



2WD AND PRE RUNNER, AUTOMATIC TRANSMISSION:




2WD AND PRE RUNNER, AUTOMATIC TRANSMISSION:




● Non-reusable part


4WD, MANUAL TRANSMISSION:





EM

4WD, MANUAL TRANSMISSION:

PROPELLER WITH CENTER
BEARING SHAFT ASSEMBLY







EM

