



Copies are Uncontrolled

Document No.: XXXXXXXX

Revision: TBD

Date: TBD

COSMOS Command and Telemetry Handbook

For the COSMOS Demo Project



Table of Contents

Table of Contents	2
Commands	3
COSMOS STARTCMDLOG	3
COSMOS STARTLOGGING	3
COSMOS STARTTLMLOG	3
COSMOS STOPCMDLOG	3
COSMOS STOPLOGGING	4
COSMOS STOPTLMLOG	4
Telemetry Packets	4
COSMOS LIMITS_CHANGE	4
COSMOS VERSION	5



Commands

COSMOS STARTCMDLOG

Starts logging commands for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode Id Value: 3	3	3	3	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to start logging on - ALL starts logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

COSMOS STARTLOGGING

Starts logging both commands and telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode Id Value: 2	2	2	2	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to start logging on - ALL starts logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

COSMOS STARTTLMLOG

Starts logging telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode Id Value: 4	4	4	4	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to start logging on - ALL starts logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

COSMOS STOPCMDLOG

Stops logging commands for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	



OPCODE	COSMOS Command Opcode Id Value: 6	6	6	6	32	32	UINT
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT
INTERFACE	Interface to stop logging on - ALL stops logging on all interfaces			ALL	96	256	STRING
LABEL	Optional label to place on log files				352	0	STRING

COSMOS STOPLOGGING

Stops logging both commands and telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode Id Value: 5	5	5	5	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to stop logging on - ALL stops logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

COSMOS STOPTLMLOG

Stops logging telemetry for an interface

Item Name	Description	Min	Max	Default	Bit Offset	Bit Size	Data Type	Units
SYNC	COSMOS Command Sync Pattern	449838109	449838109	449838109	0	32	UINT	
OPCODE	COSMOS Command Opcode Id Value: 7	7	7	7	32	32	UINT	
LENGTH	COSMOS Command Length of Command Data in Bytes	0	65536	3	64	32	UINT	
INTERFACE	Interface to stop logging on - ALL stops logging on all interfaces			ALL	96	256	STRING	
LABEL	Optional label to place on log files				352	0	STRING	

Telemetry Packets

COSMOS LIMITS_CHANGE

COSMOS limits change

Item Name	Description	Bit Offset	Bit Size	Data Type	Units Format
RECEIVED_TIMESECONDS	COSMOS Received Time (UTC, Floating point, Unix epoch) Read Conversion: ReceivedTimeSecondsConversion	0	0	DERIVED	%0.6f
RECEIVED_TIMEFORMATTED	COSMOS Received Time (Local time zone, Formatted string) Read Conversion: ReceivedTimeFormattedConversion COSMOS packet received count	0	0	DERIVED	



RECEIVED_COUNT	Read Conversion: ReceivedCountConversion	0	0	DERIVED
PKT_ID	Packet ID Id Value: 2	0	8	UINT
TARGET	Target name	8	240	STRING
PACKET	Packet name	248	240	STRING
ITEM	Item that changed limits state	488	240	STRING
OLD_STATE	The old limit state	728	240	STRING
NEW_STATE	The new limit state	968	240	STRING

COSMOS VERSION

COSMOS version information

Item Name	Description	Bit Offset	Bit Size	Data Type	Units Format
RECEIVED_TIMESECONDS	COSMOS Received Time (UTC, Floating point, Unix epoch) Read Conversion: ReceivedTimeSecondsConversion	0	0	DERIVED	%0.6f
RECEIVED_TIMEFORMATTED	COSMOS Received Time (Local time zone, Formatted string) Read Conversion: ReceivedTimeFormattedConversion	0	0	DERIVED	
RECEIVED_COUNT	COSMOS packet received count Read Conversion: ReceivedCountConversion	0	0	DERIVED	
PKT_ID	Packet ID Id Value: 1	0	8	UINT	
COSMOS	COSMOS version	8	240	STRING	
RUBY	Ruby version	248	240	STRING	
CTDB	Command Telemetry Database Version	488	240	STRING	
USER	User Version	728	240	STRING	