




USB to UART




Power




PCM




earphone




Interface




UART JMP




UART



SIM7600Cx




USB




SD_CARD

Indicator light



NET


PWR



KEY

按下开机


Antenna




Main ANT

Div ANT


GNSS ANT



SIM_CARD



Flight mode



Raspberry Interface



SIM7600X 4G HAT

REV02