

The `sdr_am_server` function is invoked in a thread

The function takes care of the refreshes required for the SDRAM

The function also handles the commands for the SDRAM. The commands supported in this implementation includes

- a) SDRAM block Write
- b) SDRAM block read
- c) SDRAM line write
- d) SDRAM line read
- e) SDRAM wait in Idle