



Reference STMicroelectronics Application Note AN4938 for details on basic STMH74x circuits



The resistors here set the gain of the transimpedance amplifiers. They should be (max expected current) * R = VREF+

