



To Make Full Wave:

- Replace D2 with 0ohm
- Remove R2 and R3
- Populate R4, R5, & R6 with 0ohm



Voltage Measurement



Current Measurement

