


Abs of absolved error value varies based on the input  
(Int, WIDTH = 16, NUM\_SEG = 16)



SW (red line)  
Min = 0, Max = 2

HW (blue line)  
Min = 0, Max = 2