


Abs of absolute error value varies based on the input
(Int, WIDTH = 32, NUM_SEG = 8)



SW (red line)
Min = 0, Max = 450

HW (blue line)
Min = 0, Max = 450