


Abs of absolved error value varies based on the input
(Int, WIDTH = 8, NUM_SEG = 16)



SW (red line)
Min = 0, Max = 1

HW (blue line)
Min = 0, Max = 1