

Z80 Retro! – ESP32 Interface and Programmer Board with WiFi

PAGE 1 : INTRODUCTION

PAGE 2 : Z80 RETRO INTERFACE

PAGE 3 : SPI <--> Z80 ADDRESS, DATA, CONTROL EXPANSION

PAGE 4 : RS232 EXTERNAL INTERFACES

PAGE 5 : ESP32 PROGRAMMER & WIFI ACCESS

Z80 Retro Interface

File: Z80Interface_sch.kicad_sch

SPI<-->Z80 Bus

File: SPItoZ80Bus.kicad_sch

RS232

File: RS232.kicad_sch

ESP32


File: ESP32.kicad_sch

MOUNTING HOLES


- 4 required for tooling
- 4 required for mechanical
- 1 extra if board connects directly above Z80-Retro main

H1 MountingHole H2 MountingHole H3 MountingHole H4 MountingHole H5 MountingHole

PROBE GND PINS



MICRO SD CARD ACTIVITY



PCB STACKUP NOTE

Use JLC04161H-3313 stackup to give :
* Lower trace impedance (~50ohms).
* GND plane closer to signal layer routing for improved signal integrity.

LOG011

LOG010



This documentation describes Open Hardware and is licensed under the CERN OHL v. 1.2.


You may redistribute and modify this documentation under the terms of the CERN OHL v.1.2. (<http://ohwr.org/cernohl>). This documentation is distributed WITHOUT ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING OF MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. Please see the CERN OHL v.1.2 for applicable conditions

Z80 Retro! – ESP32-S3 Interface and Programmer With WiFi

Title: Z80 Retro! ESP32 Interface and Programmer




Size: USLetter Date: 2023-06-12 Rev: 1.0

KiCad E.D.A. kicad 7.0.2 Drawn: Denno Wiggle Id: 1/5




SPI <--> Z80 BUS

Z80 RESET CIRCUIT



RS232


TTL RS232 HEADER



A place to add connection to external TTL level RS232 modules.

Do not connect UART0_RX to a TX source as the ESP32 USB-Serial IC is driving this signal.


J401 TTL RS232 DB9 SELECTOR



J401 RS232 Output Options
To select ESP32 Console add jumpers 3-5, 4-6 (Uart 1 selected)
To select ESP32 Debug messages add jumper 1-3 (Uart 0 selected)
Default jumper settings = Console 3-5, 4-6 (Uart 1)

ESP32 Console / Download option on uart 1 set in SW.

DUAL RS232



RS232 EXTERNAL INTERFACES

Title: Z80 Retro! ESP32 Interface and Programmer

Size: USLetter Date: 2023-06-12 Rev: 1.0

KiCad E.D.A. kicad 7.0.2 Drawn: Denno Wiggle Id: 4/5

