

\*\*\*\*\*Draft\*\*\*\*\*

## Modifng Computing Options

04/16/20


\*\*\*\*\*Draft\*\*\*\*\*

This the temperature with a top around 4.


```
sudo cat /sys/class/thermal/thermal_zone0/temp
```

55991 55.991 is the temperature C.


Simple View. (default)



Advance View.



Computing options (default)



2of4 CPUs.

**BOINC - Computing preferences** [X]

◀ [Gears] Computing [Up Arrow] Network [Down Arrow] Disk and memory ▶

**Usage limits**

Use at most  % of the CPUs

Use at most  % of CPU time

**When to suspend**

☒ Suspend when computer is on battery

☐ Suspend when computer is in use

☒ Suspend GPU computing when computer is in use

'In use' means mouse/keyboard input in last  minutes

☒ Suspend when non-BOINC CPU usage is above  %

To suspend by time of day, see the "Daily Schedules" section.

**Other**

Store at least  days of work

Store up to an additional  days of work

Switch between tasks every  minutes

Request tasks to checkpoint at most every  seconds

Save [X] Cancel Help