












删除R19，R42

Title			
<Title>			
Size	Document Number		Rev
A	<Doc>		<RevCode>
Date:	Friday, June 17, 2016		Sheet 1 of 5




Title			<Title>
Size	Document Number	Rev	
B	<Doc>	<RevCode>	
Date:	Friday, June 17, 2016	Sheet	2 of 5







风扇驱动电路1

err: TX 与RX连反了




该接口必须是2.54mm间距
此处使用的是模块，注意封装大小






LED电路


检查几个电阻的阻值是否太小?




此处管脚间距需要重新定一下，需要和机器一致，直接插即可



Title		<Title>	
Size	Document Number	Rev	
C	<Doc>	<Rev Code>	
Date:	Friday, June 17, 2016	Sheet	4 of 5



电池充电电路



Title		<Title>
Size	Document Number	Rev
C	<Doc>	<Rev Code>
Date:	Friday, June 17, 2016	Sheet 5 of 5