

Risk-Based
Geomechanical
Screening

Stress Man

MUDLINE SUBSIDENCE

FAULT
ACTIVATION

CASING CRUSHING

COMPACTION DRIVE

CASING
SHEAR

SAND PRODUCTION

RESERVOIR YIELD

PERMEABILITY LOSS

CASING BUCKLING

