



Barnett: Normal Faulting
stress regime

HF (plane) \perp S_{hmin}

H_z well \parallel S_{hmin}

$P_{BHP} > S_{hmin}$