

Effective stress =
Total stress – Pore pressure

$$\sigma = S - p$$

