



transmission pinout for F4A4 F5A4 F5A5 W4A4 W4A5 W5A4 W5A5


(All Cars) (Gandis/ Charriot) (RVR) (Airtrek) (Galant) (GTA) (Special Note)




RVR [A-92]		
Small black plug		
1	Ground	B
2	A/T; Input shaft speed sensor	O
3	+12v	B-Y
<div><div>GTA</div><div><div></div><div></div><div></div></div><div>RVR</div><div><div></div><div></div><div></div></div></div>		



RVR [A-91]		
Large black plug		
1	A/T; Drive inhibit switch	
2		
3	A/T; Park inhibit switch	
4	A/T; Neutral inhibit switch	
5		
6	N/C	
7	A/T; Reverse inhibit switch	
8	12v Ignition switch inhibit supply (crank) ground (GTA)	
9	E/C; Neutral/park start inhibit switch (SH4 only)	
10	E/C; 12v Ignition switch Start Signal (crank) (SH4 only)	
<div><div>GTA</div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div><div>RVR</div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div>		



RVR [A-87]		
Small grey plug		
1	Ground	B
2	A/T; O'put shaft spd sensor	L-Y
3	+12v	B-Y
<div><div>GTA</div><div><div></div><div></div><div></div></div><div>RVR</div><div><div></div><div></div><div></div></div></div>		



RVR [A-90]		
Large grey plug		
1	A/T; oil temp Sensor	
2	A/T; oil temp Sensor Return	
3	A/T; Underdrive solenoid	
4	A/T; Second Clutch solenoid	
5	A/T; Overdrive solenoid	
6	A/T; Low/reverse solenoid	
7	A/T; Lockup DCC solenoid	
8	Reduction Solenoid (5 speed only)	
9	A/T Control Relay	
10	A/T Control Relay	
<div><div></div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div><div>RVR</div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div>		