

**STATS DISPLAY**

---



---



---



---



---



---



---



---



---



---

Name

---

Make & model

---

<b>ARMOUR</b>	<b>TRACKING LOCK</b>
<u>AC</u>	<u>TL</u>
<b>DAMAGE THRESHOLD</b>	<b>CRITICAL</b>
<u>DT</u>	<u>CT</u>

---

<b>SIZE</b>	Speed	Turning
<u>          </u>	<u>                </u>	<u>                </u>
<u>          </u>		
<u>          </u>		


---

**INITIATIVE**







**INITIATIVE  
MARKER**

Name \_\_\_\_\_



## HEX TOKENS

1.  Cut out carefully with a sharp knife or scissors, using the | marks as guides
2.  Fold along the dotted lines, making sure the  hatched areas are hidden or face down
3.  Optionally, fix it with glue