



Note: If U2 is not placed, J3 can be used to connect a through-hole amplifying resistor **edgecollective**

Sheet: /
File: conductive.sch

Title: Conductivity-board

Size: A4	Date:	Rev: 0.1
KiCad E.D.A. kicad no-vcs-found-1fe91e659ubuntu17.04.1		Id: 1/1