


Kit 3: Building a robot

Circuit:



Create your own chassis as the kit does not come with it's own. You can make it whatever shape you want as long as the above wiring is used.

Steps:

1. Go to Menu, Programming, Python 3 and then File, New File.
2. Press CTRL+S on your keyboard.
3. Save it as 1-test.py
4. Type:

```
from edupy import *  
  
forward()  
sleep(1)  
backward()  
sleep(1)  
turn_left()  
sleep(1)  
turn_right()  
sleep(1)
```

5. Press CTRL + S on your keyboard.
6. Press F5 on your keyboard.
7. Your program will now run. Press CTRL+C to stop it running.