



[SHP-8] [The connection with the weather station does not work on Raspberry Pi OS](#) Created: 01/May/23 Updated: 01/May/23 Resolved: 01/May/23

Status:	Done
Project:	ShipRealWindCalculator
Components:	None
Affects versions:	None
Fix versions:	None

Type:	Bug	Priority:	High
Reporter:	Elena-Gratiela Robe-Voinea	Assignee:	Elena-Gratiela Robe-Voinea
Resolution:	Done	Votes:	0
Labels:	None		
Remaining Estimate:	Not Specified		
Time Spent:	Not Specified		
Original estimate:	Not Specified		

Attachments:	 1331_step3.jpg  1331_step3.mp4
Rank:	0 i000jz:
Sprint:	SHP Sprint 2
Expected result:	The “ON“ button is pressed and therefore the Input parameters start to load, which means that the connection with the weather station is established.
Actual result:	Input parameters doesn't start to load.
Step to reproduce:	<ol style="list-style-type: none">1. Acces the app ShipReal Wind Calculator from Raspberry Pi OS.2. Press the “ON“ button.
Environment:	Testing
Operating system:	Raspberry Pi

Description

When the user press the "ON" the Input parameters doesn't start to load, which means that the connection with the weather station does not work