

## (wafer2,0,7,-1,-1,0,1) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 38
- Last Stimulated = 2022/March/28 at 04:56:29PM

-----  
Stimulated at 04:55:37PM on 2022/March/25

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set, but too high to tell accurately ~5V

### Probe A plots



## Probe B plots



-----  
Stimulated at 04:56:27PM on 2022/March/25

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V


Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set\*

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:57:52PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset

### Probe A plots



## Probe B plots



-----  
Stimulated at 04:58:11PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did not reset again

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:58:30PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did reset, slope not constant

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:59:44PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = Set at 2.35V



## Probe A plots



## Probe B plots



Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Did reset, but was erratic. rr not maintained

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:01:31PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 4.50V

## Probe A plots



## Probe B plots



Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset, rr not maintained

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:03:10PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 20.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 4.35V

## Probe A plots



## Probe B plots



Activity = reset

Start Voltage = 0V

End Voltage = -3V

Ramp Rate = 1V/s

Compliance Current = 6.0mA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = Reset, similar slope to previous reset

### Probe A plots





## Probe B plots



-----  
Stimulated at 05:51:10PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 30.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 4.45V

## Probe A plots



## Probe B plots



-----  
Stimulated at 05:51:42PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset, not constant slope

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:52:30PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 30.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.45V

## Probe A plots



## Probe B plots



Stimulated at 05:52:56PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset, slope opposite of expected

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:54:33PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 30.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.65V

## Probe A plots



## Probe B plots



-----  
Stimulated at 05:54:57PM on 2022/March/25

Activity = reset



Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset similar to previous run

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:56:26PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.25V

## Probe A plots



## Probe B plots



-----  
Stimulated at 05:57:04PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:57:32PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = set at 4.25V

## Probe A plots



## Probe B plots



-----  
Stimulated at 05:57:58PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

### Probe A plots



## Probe B plots



-----  
Stimulated at 05:58:48PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = Set at 2.6V



## Probe A plots



## Probe B plots



-----  
Stimulated at 05:59:12PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Reset, but weird



## Probe B plots



-----  
Stimulated at 05:59:35PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.4V, (ignore)

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:00:32PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Connection Issues (ignore)

### Probe A plots



## Probe B plots



-----  
Stimulated at 06:02:48PM on 2022/March/25

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 20.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V


Run Folder Name = <2 probe, so invalid>

Comments = Not conducting State: Reset\*

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:03:27PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = Set at 3.45V, (ignore)

## Probe A plots





## Probe B plots



-----  
Stimulated at 06:04:05PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset, looks odd

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:05:15PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 40.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.5V

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:05:39PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset

## Probe A plots



## Probe B plots



-----  
 Stimulated at 06:06:01PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s

Compliance Current = 40.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 2.2V

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:06:24PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Reset nicely

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:06:43PM on 2022/March/25

Activity = set

Start Voltage = 0V

End Voltage = 5V



Ramp Rate = 1V/s

Compliance Current = 40.0uA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.25V

## Probe A plots



## Probe B plots



-----  
Stimulated at 06:07:10PM on 2022/March/25

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Good Reset, really close slope to previous reset

## Probe A plots



## Probe B plots



-----  
 Stimulated at 04:54:12PM on 2022/March/28

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V


Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Set State: Set\*



## Probe B plots



-----  
Stimulated at 04:55:05PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Decided not to Reset

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:55:38PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 8.0mA


Platinum Voltage =

Copper Voltage =


Run Folder Name = <2 probe, so invalid>

Comments = Didn't Reset

## Probe A plots



## Probe B plots



-----  
Stimulated at 04:56:29PM on 2022/March/28

Activity = reset

Start Voltage = 0V

End Voltage = -5V

Ramp Rate = 1V/s

Compliance Current = 10.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>


Comments = Didn't Reset, following Ohms law



## Probe A plots



## Probe B plots



-----