

B

2

1

Wrap tape around noodles
and attach to wood

Drill through the bracket
into marked spots on wood

B

Use tape to attach front noodles

A

A

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
<INSERT COMPANY NAME HERE>. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
<INSERT COMPANY NAME HERE> IS
PROHIBITED.

		UNLESS OTHERWISE SPECIFIED:		NAME	DATE	TITLE:
		DIMENSIONS ARE IN INCHES		DRAWN		
		TOLERANCES:		CHECKED		
		FRACTIONAL \pm		ENG APPR.		
		ANGULAR: MACH \pm BEND \pm		MFG APPR.		
		TWO PLACE DECIMAL \pm		Q.A.		SIZE DWG. NO. REV
		THREE PLACE DECIMAL \pm		COMMENTS:		
		INTERPRET GEOMETRIC TOLERANCING PER:				
		MATERIAL				Bumper half frame
		FINISH				
NEXT ASSY	USED ON	APPLICATION	DO NOT SCALE DRAWING			SCALE: 1:10 WEIGHT: SHEET 1 OF 1

2

1