


# LED EXTERNAL T5

## T5 Tube w/ External Driver System

The LED External Tube w/ external driver system replace traditional T5 systems. One driver for 1, 2, 3 or 4 LED tubes available.



## DIMENSIONS



## CERTIFICATIONS



## FEATURES

- Can be dimmable or non dimmable
- Special circuit design, having the single broken LED influence problem
- External Class 2 Driver System
- Soft and wide light emitting
- Ultra slim and unlimited design and various dimensions available
- Minimize labor and recycling costs
- No infrared rays, no ultraviolet radiation, and no thermal effect
- UL Type C
- 5 Year Manufacturer's Warranty

## COMMON TECHNICAL DATA

Color Temperature	3000K to 5000K
Beam Angle	120°
CRI	> 80
Operation Temperature	-20°C to 50°C
Efficiency	140 LPW
Input Voltage	AC100-277V / AC100-382V
Frequency	50-60Hz
Power Supply Efficiency	99%
Rated Life	50,000 hours
Power Factor	More than 0.99
LED Type	SMD 2835
Housing	Aluminum/PC

## WARRANTY

This product has a warranty for a period of 5 years from the date of purchase. The warranty is invalid in the case of improper installation, tampering, or removal of the Q.C. date label. Installation in an improper working environment or installation not according to the current edition of the National Electric Code also invalidates the warranty. Should this product fail during the warranty period, it will be replaced free of charge, subject to correct installation and return of the faulty unit. James® does not accept responsibility for any installation costs associated with the replacement of this product. This warranty is in addition to the statutory rights in the country of purchase. James® reserves the right to alter specifications without prior notice.

# LED EXTERNAL T5

T5 Tube w/ External Driver System

## PRODUCT SPECIFICATION

Product code	Dimmable	Length (FT)	Wattage	Color	Lumens	Multiple Driving Type	Driver	Wire input
ZY-T5-15W1200 BONT	No	4FT	15W	3000K-5000K	2100	One driver for 1,2,3 and 4 tubes	External	Two End
ZY-T5-15W1200 BODT	Yes							
ZY-T5-18W1200 BONT	No	4FT	18W	3000K-5000K	2100	One driver for 1,2, and 3 tubes	External	Two End
ZY-T5-18W1200 BODT	Yes							
ZY-T5-22W1200 BONT	No	4FT	22W	3000K-5000K	3080	One driver for 1,2 or 3 tubes	External	Two End
ZY-T5-22W1200 BODT	Yes							
ZY-T5-25W1200 BONT	No	4FT	25W	3000K-5000K	3405	One driver for 1,2 or 3 tubes	External	Two End
ZY-T5-25W1200 BODT	Yes							
ZY-T5-30W1200 BONT	No	4FT	30W	3000K-5000K	4200	One driver for 1 or 2 tubes	External	Two End
ZY-T5-30W1200 BODT	Yes							


## ORDERING GUIDE

ZY	T5	15/18/22/25/30	600/1200	B	O	DT/NT	3000K-5000K
Company Code	Housing Type	Wattage	Length	2835 LED	External Driver	Input Type	CCT

## INSTALLATION INSTRUCTIONS

Direct Replacement Procedure:

1. Turn OFF power to the fixture at the breaker panel before installation.
2. Open the diffuser from the light fixture.
3. Remove the fluorescent tubes and dispose of these properly as they may contain mercury.
4. Make the new wire connection (A) to the branch circuit and.
5. Install the LED tubes ensure the pins are firmly seated in lamp holders and close the diffuser.
6. Switch ON power to the fixture at the breaker panel



## CAUTION

- Risk of fire- do not install this lamp in a pre-heated luminaire.
- Loose or damaged end caps and/or lamp holders need to be replaced before installation.
- Risk of electric shock- make installation with gloves.
- Use only in place of fluorescent lamps specified on label.
- These lamps are intended for use with emergency exists.
- These lamps are to be used with a light dimmer.
- If the lamp or luminaire exhibits undesirable operation (i.e. buzzing, flickering, etc.), immediately turn off power and remove the lamp from luminaire and contact manufacturer.
- Not suitable for wet locations.
- Do not make mass installation before sample testing.