



1. Transmission
2. Oil pressure switch and pressure transmitter manifold
3. Packing
4. Oil pressure switch
5. Electrical connector

212-M-63-39

Figure 63-39. Transmission oil switch