


1. Nut
2. Washer
3. Spacer
4. Wafer screens
5. Filter body
6. Name plate



**NOTES:**

1. Straighten tangs on washer (2) and remove nut (1)
2. Remove wafer screens (4) and spacers (3) from body (5).
3. Install new washer (2) upon reassembly of filter

212-M-63-23

**Figure 63-23. Sump internal filter**