

Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 1 of 14)






Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 3)







Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 4)



212-M-98-9-5
212-475-012H



98-00-00
Page 37




Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 7)




Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 8)




Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 9)


























Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 10)



BHT-212-MM



- NOTES**
- 1 REFER TO STATION NUMBER 457 WHEN TRANSMISSION IS MODIFIED FOR CHIP INDICATION PROVISION.
2. THIS SHEET USES STATION NUMBERS 333 THROUGH 358.

Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 11)






Figure 98-9. Electrical master wiring diagram (S/N 30554 through 30596) (Sheet 13)

