


1. Defueling valve
2. Crossover assembly
3. Sump base
4. Nut retainer
5. Pressure hose
6. Fuel low warning switch
7. Support
8. Pump outlet
9. Flow line hose
10. Check valve
11. Flow switch
12. Union
13. Flow hose
14. Quantity probe connector

15. Gasket
16. Boost pump
17. Ground jumper
18. Seal drain adapter
19. Pump outlet plug
20. Pump drain valve
21. Sump drain valve
22. Terminal block



NOTE

1 Effective on helicopter S/N 31312 and subsequent and helicopters with P/N 206-062-687-101 fuel boost pumps.

212-M-28-7

Figure 28-7. Fuel cell sump (left side typical)