



ROUTE TRACKER CABLE AS SHOWN
SO THAT IT ENTERS COCKPIT AT LOWER
FORWARD CORNER OF COPILOT DOOR.
SECURE WITH DUCT TAPE.

DO NOT LET TRACKER CABLE OR
TAPE COVER AIRSPEED STATIC PORTS.

212-M-18-8

Figure 18-8. Passive optical tracker location and cable routing