


CONTENTS - IPB

Figure Number	Figure Title	Chapter/Section Number	Page Number
26-1	Fire extinguisher installation	26-99-00	2



212_IPB_26_0001

Figure 26-1. Fire Extinguisher Installation

(1) INDEX NUMBER	(2) PART NUMBER	(3) ITEM NAME	(4) UNIT PER ASSY	(5) A V A I L	(6) U O C
		Figure 26-1. Fire Extinguisher Installation			
	212-060-904-003	FIRE EXTINGUISHER INSTL	1	NP	
1	NAS679A3	.NUT (REPLACED BY MS21042L3)	4	P	
1	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	4	SP	
2	AN960C10L	.WASHER (REPLACED BY NAS1149C0332R)	4	P	
2	NAS1149C0332R	.WASHER (REPLACES AN960C10L)	4	SP	
3	MS27039-1-08	.SCREW	4	SP	
4	MS9825-12	.CLAMP	4	SP	
5	212-060-933-001	.TUBE ASSY, LH	1	SP	
5	212-060-934-001	.TUBE ASSY, RH (REPLACED BY 212-060-935-005)	1	NP	
5	212-060-935-005	.TUBE ASSY, RH (REPLACES 212-060-934-001)	1	SP	
6	NAS679A3	.NUT (REPLACED BY MS21042L3)	8	P	
6	MS21042L3	.NUT, SELF-LOCKING (REPLACES NAS679A3)	8	SP	
7	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	8	P	
7	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	8	P	
7	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	8	SP	
8	MS27039-1-11	.SCREW	8	SP	
9	MS20760-12-16	.ADAPTER	2	SP	
10	MS20760-16	.ADAPTER	2	SP	
11	212-060-921-001	.MANIFOLD ASSY, LH	1	SP	
11	212-060-921-002	.MANIFOLD ASSY, RH	1	SP	
12	AN924-16	.NUT	2	SP	
13	AN960C2116	.WASHER (REPLACED BY NAS1149C2190R)	4	P	
13	NAS1149C2190R	.WASHER (REPLACES AN960C2116)	4	SP	
14	50-038-1	.FITTING	2	SP	
15	212-060-936-001	.TUBE ASSY	1	SP	
16	212-060-930-001	.TUBE ASSY	1	SP	
17	212-060-919-001	.TUBE ASSY, LH	1	SP	
17	212-060-915-001	.TUBE ASSY, RH	1	SP	
18	AN3-4A	.BOLT	8	SP	
19	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	8	P	
19	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	8	P	
19	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	8	SP	
20	NAS679A4	.NUT (REPLACED BY MS21042L4)	4	P	
20	MS21042L4	.NUT (REPLACES NAS679A4)	4	SP	
21	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	4	NP	
21	AN960JD416L	.WASHER (REPLACES AN960PD416L) (REPLACED BY NAS1149D0416J)	4	P	
21	NAS1149D0416J	.WASHER (REPLACES AN960JD416L)	4	SP	
22	AN4-5A	.BOLT	4	SP	
23	AN4-5A	.BOLT	2	SP	
24	AN960PD416L	.WASHER (REPLACED BY AN960JD416L)	2	NP	
24	AN960JD416L	.WASHER (REPLACES AN960PD416L) (REPLACED BY NAS1149D0416J)	2	P	
24	NAS1149D0416J	.WASHER (REPLACES AN960JD416L)	2	SP	
25	212-060-917-001	.SUPPORT ASSY, LH	1	SP	
25	212-060-917-002	.SUPPORT ASSY, RH	1	SP	
26	MS21042L06	.NUT	12	SP	
27	AN960C6L	.WASHER (REPLACED BY NAS1149CN616R)	12	SP	

(1) INDEX NUMBER	(2) PART NUMBER	(3) ITEM NAME	(4) UNIT PER ASSY	(5) A V A I L	(6) U O C
		Figure 26-1. Fire Extinguisher Installation (Cont'd)			
27	NAS1149CN616R	.WASHER (REPLACES AN960C6L)	12	SP	
28	MS35206-229	.SCREW	12	SP	
29	209-062-911-001	.INDICATOR, DISCHARGE	2	SP	
30	MS21042L3	.NUT, SELF-LOCKING	1	SP	
31	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
31	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	1	P	
31	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
32	MS27039-1-05	.SCREW	1	SP	
33	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	NP	
33	MS21919WDG6	.CLAMP (REPLACES MS21919DG6)	1	SP	
34	70-010F098F180	.HOSE ASSY (REPLACED BY 70-061F098F180A)	1	P	
34	70-061F098F180A	.HOSE ASSY (REPLACES 70-010F098F180)	1	SP	
35	AN816-4	.NIPPLE (REPLACED BY AN816-4J)	1	SP	
35	AN816-4J	.NIPPLE (REPLACES AN816-4)	1	SP	
36	MS21042L3	.NUT, SELF-LOCKING	1	SP	
37	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	1	P	
37	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	1	P	
37	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	1	SP	
38	MS27039-1-12	.SCREW	1	SP	
39	MS21919DG6	.CLAMP (REPLACED BY MS21919WDG6)	1	NP	
39	MS21919WDG6	.CLAMP (REPLACES MS21919DG6)	1	SP	
40	NAS43DD3-24	.SPACER (REPLACED BY NAS43DD3-24N)	1	P	
40	NAS43DD3-24N	.SPACER (REPLACES NAS43DD3-24)	1	SP	
41	70-010F208F180	.HOSE ASSY (REPLACED BY 70-061F208F180A)	1	NP	
41	70-061F208F180A	.HOSE ASSY (REPLACES 70-010F208F180)	1	SP	
42	AN816-4	.NIPPLE (REPLACED BY AN816-4J)	1	SP	
42	AN816-4J	.NIPPLE (REPLACES AN816-4)	1	SP	
43	212-060-918-005	.SUPPORT ASSY, LH	1	SP	
43	212-060-918-006	.SUPPORT ASSY, RH	1	SP	
44	209-062-908-001	.CONTAINER, FIRE EXTINGUISHER (REPLACED BY 209-062-908-105)	2	NP	
44	209-062-908-105	.CONTAINER, FIRE EXTINGUISHER (REPLACES 209-062-908-001)	2	SP	
		(ALTERNATE PARTS)			
44	209-062-908-107	.CONTAINER, FIRE EXTINGUISHER (REPLACED BY 209-062-908-111)	2	NP	
44	209-062-908-111	.CONTAINER, FIRE EXTINGUISHER (REPLACES 209-062-908-107)	2	SP	
45	243401	..GAUGE (NOTE 1)	1	SP	
45	2725709	..GAUGE (NOTE 2) (REPLACED BY 19915515-1)	1	NP	
45	19915515-1	..GAUGE (NOTE 2) (REPLACES 2725709)	1	SP	
	205-070-300-001	FIRE EXTINGUISHER INSTL	1	NP	
46	MS27039-1-10	.SCREW	4	SP	
47	AN960PD10L	.WASHER (REPLACED BY AN960JD10L)	4	P	
47	AN960JD10L	.WASHER, FLAT (REPLACES AN960PD10L) (REPLACED BY NAS1149D0332J)	4	P	
47	NAS1149D0332J	.WASHER, FLAT (REPLACES AN960JD10L)	4	SP	
48	AN960PD416	.WASHER (REPLACED BY AN960JD416)	4	NP	

(1) INDEX NUMBER	(2) PART NUMBER	(3) ITEM NAME	(4) UNIT PER ASSY	(5) A V A I L	(6) U O C
		Figure 26-1. Fire Extinguisher Installation (Cont'd)			
48	AN960JD416	.WASHER, FLAT (REPLACES AN960PD416) (REPLACED BY NAS1149D0463J).....	4	P	
48	NAS1149D0463J	.WASHER (REPLACES AN960JD416)	4	SP	
49	FR2 1-2	.FIRE EXTINGUISHER (REPLACED BY 50-049-1 AND 40000).....	1	NP	
49	50-049-1	.FIRE EXTINGUISHER (REPLACES FR2 1-2) (REPLACED BY 40000).....	1	NP	
50	50-049-3	..FIRE EXT BRACKET (USE WITH 50-049-1)	1	SP	
51	40000	.FIRE EXTINGUISHER (REPLACES FR2 1-2 AND 50-049-1)	1	SP	
		(ALTERNATE PART)			
51	600W	.FIRE EXTINGUISHER	1	SP	
52	412-070-006-105	.SUPPORT ASSY (USE WITH 40000)	1	SP	
53	412-070-006-107	..CLAMP ASSY	1	P	
	205-070-305-003	FIRE EXTINGUISHER INSTL (S/N 30504 THRU 31111) (S/N 35001 THRU 35097).....	1	NP	
	205-070-300-101	FIRE EXTINGUISHER INSTL (S/N 35098 THRU SUB)	1	NP	
54	AN3-3A	.BOLT	4	SP	
55	AN960-10L	.WASHER (REPLACED BY NAS1149F0332P)	4	P	
55	NAS1149F0332P	.WASHER (REPLACES AN960-10L)	4	SP	
56	FR2 1-2	.FIRE EXTINGUISHER (REPLACED BY 50-049-1, 40301R, 43301 AND 40000).....	1	NP	
56	50-049-1	.FIRE EXTINGUISHER (NOTE 3)(REPLACES FR2 1-2) (REPLACED BY 40301R).....	1	NP	
57	50-049-3	..FIRE EXT BRACKET	1	SP	
58	40301R	.FIRE EXTINGUISHER (NOTE 3)(REPLACES FR2 1-2 AND 50-049-1)	1	SP	
59	412-070-006-109	.SUPPORT ASSY	1	SP	
60	412-070-006-103	..CLAMP ASSY	1	SP	
61	MS27039-1-10	.SCREW	4	SP	
62	NAS1149D0332K	.WASHER	4	SP	
		NOTE 1: USE RECHARGE KIT 804555 PLUS CARTRIDGE 209-062-908-013 AND -017 FOR WALTER KIDDE CONTAINER CONFIGURATION.			
		NOTE 2: USE RECHARGE KIT P13177 (05167) PLUS CARTRIDGE 209-062-908-015 AND -019 FOR AMERICAN STANDARD CONTAINER CONFIGURATION.			
		NOTE 3: WHEN REPLACING 50-049-1 FIRE EXTINGUISHER WITH 40301R FIRE EXTINGUISHER USE WITH 412-070-006-109 SUPPORT ASSEMBLY. DISCARD MOUNTING BRACKET SUPPLIED WITH 40301R FIRE EXTINGUISHER.			

(1) INDEX NUMBER	(2) PART NUMBER	(3) ITEM NAME	(4) UNIT PER ASSY	(5) A V A I L	(6) U O C
		<p>Figure 26-1. Fire Extinguisher Installation (Cont'd)</p> <p>AVAIL CODE DEFINITION</p> <p>P Procurable</p> <p>NP Non Procurable</p> <p>SP Normal Stock/Procurement</p> <p>See introduction on availability codes for additional information.</p>			