




BUCK CONVERTER



A₁
Do not power the system before POT1 is set.
Otherwise, whole system could be damaged.
5V5 --> 3.47Kohm
5V4 --> 3.39Kohm
5V5 --> 3.31Kohm
Resistance increases by turning to CV

Project:	LM2596ADJ Breakout	Variant:	[No Variations]
Page Name:	LM2596ADJ Breakout.SchDoc		
Designed By:	Enes Mercan	ApprovedBy:	
Date:	29/03/2022	Page Size:	A3
		Sheet:	1 of 1
		Revision:	v1.0