












Arduino_P11 PointSelectorEncoderA
 Arduino_P10 PointSelectorEncoderB
 Arduino_P9 PointSelectorSwitch
 Arduino_P8 LedMatrixData
 Arduino_P7 ConfettiCannon
 Arduino_P6 StartResetSignal
 Arduino_P5 GameModeSignal
 Arduino_P4 PlayerCountSignal
 Arduino_P3 Serial_MicroBit_RX_Enable_5V
 Arduino_P2 Serial_Arduino_RX_Enable_5V
 Arduino_P1 Serial_Arduino_TX_5V
 Arduino_P0 Serial_Arduino_RX_5V

Notch of the IDC connectors (see list) on this side:
 - Arduino_GPIO
 - Arduino_SerialLand_5V
 - MicroBit_40PinExtender

MicroBit_P16 Serial_MicroBit_TX_3V3
 MicroBit_P15 Serial_MicroBit_RX_3V3
 MicroBit_P14 LedDataTarget4_3V3
 MicroBit_P13 LedDataTarget3_3V3
 MicroBit_P2 LedDataTarget2_3V3
 MicroBit_P12 SwitchTarget4
 MicroBit_P11 SwitchTarget4
 MicroBit_P10 SwitchTarget4
 MicroBit_P9 LedDataTarget1_3V3
 MicroBit_P8 LedDataTarget1_3V3
 MicroBit_P1 SwitchTarget3
 MicroBit_P7 SwitchTarget2
 MicroBit_P6 Serial_MicroBit_RX_Enable_3V3
 MicroBit_P5 SwitchTarget2
 MicroBit_P4 SwitchTarget1
 MicroBit_P0 SwitchTarget1
 MicroBit_P3 Serial_Arduino_RX_Enable_3V3



Inside this space means the components are on the main board



The start/reset switch is connected to the Arduino pin which has an internal pull-up resistor with a value between 20K-50K ohm. (Some measured around 35K)

De Bibliotheek Eindhoven – MakersClub

Sheet: /
 File: RocketLaunchCircuit.sch

Title: RocketLaunch

Size: A4
 KiCad E.D.A. kicad (5.1.6)–1

Date: 2020-04-07
 Rev:
 Id: 1/1