



NOTE: THE ARDUINO IDE (TOOLCHAIN) DOES NOT YET SUPPORT 328PB (iom328pb.h will show up with avr-libc when it does)

WARNING: SDA1 AND SCL1 ARE 0V AND 5V WHEN ATMEGA328P IS USED

- Reference Designators:
- B Battery
 - C Capacitor
 - D Diode
 - F Fuse/Breaker
 - H Hardware & Outline
 - J Connector/Link
 - K Relay
 - L Inductor
 - M Motor (and Related)
 - P Power supply
 - Q Transistor
 - R Resistor
 - S Switch
 - T Transformer
 - TP Test point
 - U Integrated circuit/module
 - Y Crystal or oscillator

				Copyright (C) 2016 Ronald Sutherland Released under the Creative Commons Attribution-ShareAlike 4.0 International (CC BY-SA 4.0) http://creativecommons.org/licenses/by-sa/4.0/	SIZE B
BK black BN brown RD red OG orange YE yellow		GN green BU blue VT violet GY gray WH white		Symbols = RD Names = BU Values = GY Label/info = VT Busses = Dark BU Net/Wire = GN Guide = YE	
DATE: 10/16/16		NAME: RON S		ADDR: R. SUTHERLAND 1627 W INVERNESS DR TEMPE AZ 85282 E-MAIL: rsutherland at epccs dot com	
TO: 10/16/16		FROM: 8/27/16		DESCRIPTION: 328P[B] WITH SOLAR CC FOR 12V SLA	
REV 1		JDATE 1/4/16		MODEL: RPUNO	
1/1		12/2/2016 6:07 PM		DRAWING: 14140	