

**NAME**

luminance-boundaries – calculate luminance boundaries

**SYNOPSIS**

**luminance-boundaries** *input.hdr output.png*

**DESCRIPTION**

Calculate luminance boundaries using the Canny edge detector as in **deva-visibility**. Input is a Radiance .hdr image. Output is a PNG file with luminance boundary elements having a value of 255 and all other elements having a value of 0.

**AUTHOR**

William B. Thompson