

## Panel drawing

-----view from topside

## V-CUT

two arrow tip add top copper on breakaway frame

## V-CUT

