












## Edge Retractable Banner Stand Setup Instructions



## Graphic to top rail attachment





## Graphic to base attachment






Place additional masking tape to the back of the graphic for extra protection

3



Remove pin while holding onto the graphic so the graphic does not retract back in quickly

4



Slowly retract the graphic back into the base

5