













# Verse Retractable Banners Setup Instructions




## Graphic to top rail attachment




## Graphic to base attachment





Remove pin while holding onto the graphic so the graphic does not retract back in quickly.

4



Slowly retract the graphic back into the base.

5