



Hopup

A variety of sizes, kits and options of Hopup displays are available.

Hopup tension fabric displays are simple, versatile and can be set up in seconds. Hopups feature a lightweight, durable frame that holds a curved or straight fabric mural. Simply attach the graphic, pop (expand) the frame and you have an exhibit. All curved and straight Hopups are available with and without end caps.



Stabilizer feet on all straight frames 3 quads high



In-molded Velcro end-caps

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

features and benefits:

- Lighter weight anodized silver frame with a smaller footprint
- Stabilizer feet on all straight frames 3 quads high
- Grey in-molded Velcro end caps
- Supports an integrated fabric graphic mural (end caps also available)

dimensions:

Hardware:

Straight Frames:

- 1x1: 31"w x 31"h x 12"d
- 1x3: 31"w x 90"h x 29"d
- 2x1: 60.5"w x 31"h x 12"d
- 2x2: 60.5"w x 60.5"h x 12"d
- 3x2: 89.5"w x 60.5"h x 12"d
- 2x3: 60.5"w x 90"h x 29"d
- 3x3: 89.5"w x 90"h x 29"d
- 3x4: 89.5"w x 119"h x 29"d
- 4x3: 119"w x 90"h x 29"d
- 4x4: 119"w x 119"h x 29"d
- 5x3: 147.25"w x 90"h x 29"d
- 5x4: 147.8"w x 119"h x 29"d
- 6x3: 178"w x 90"h x 29"d
- 8x3: 235.43"w x 90"h x 29"d
- 12x3: 352.28"w x 90"h x 29"d

Curved Frames:

- 1x3: 31"w x 90"h x 12.5"d
- 2x1: 64"w x 31"h x 18"d
- 2x2: 64"w x 60.5"h x 18"d
- 3x2: 92"w x 60.5"h x 23"d
- 2x3: 64"w x 89.5"h x 18"d
- 3x3: 92"w x 89.5"h x 23"d
- 3x4: 92"w x 119"h x 23"d
- 4x3: 116.25"w x 89.5"h x 33"d
- 4x4: 116.25"w x 119"h x 33"d
- 5x3: 136.5"w x 89.5"h x 42"d
- 5x4: 136.5"w x 119"h x 42"d
- 6x3: 154"w x 89.5"h x 61.25"d

Graphics:

Refer to related graphic template for more information.

Visit exhibitors-handbook.com/graphic-templates

- Easy assembly
- Rolling carry bag included with most units
- LED lighting available
- Lifetime hardware warranty against manufacturer defects
- Graphics sizes changed slightly due to new frame sizes yet old graphics are compatible with new frames

Shipping: All kits ship in one box

Straight Frames:

- 1x1: 37"l x 10"w x 10"h / 10 lbs.
- 1x3: 37"l x 10"w x 10"h / 10 lbs.
- 2x1: 37"l x 10"w x 10"h / 12 lbs.
- 2x2: 37"l x 10"w x 10"h / 16 lbs.
- 3x2: 37"l x 13"w x 12"h / 21 lbs.
- 2x3: 37"l x 13"w x 12"h / 24 lbs.
- 3x3: 37"l x 13"w x 12"h / 28 lbs.
- 3x4: 37"l x 15"w x 13"h / 35lbs.
- 4x3: 37"l x 15"w x 13"h / 35 lbs.
- 4x4: 37"l x 15"w x 13"h / 34 lbs.
- 5x3: 37"l x 15"w x 13"h / 37 lbs.
- 5x4: 37"l x 18" w x 13"h / 41lbs.
- 6x3: 37"l x 18"w x 13"h / 43 lbs.
- 8x3: 37"l x 30"w x 11"h / 70 lbs.
- 12x3: 37"l x 30"w x 11"h / 86 lbs.


Curved Frames:

- 1x3: 37"l x 10"w x 10"h / 10 lbs.
- 2x1: 37"l x 10"w x 10"h / 12 lbs.
- 2x2: 37"l x 10"w x 10"h / 16 lbs.
- 3x2: 37"l x 13"w x 12"h / 21 lbs.
- 2x3: 37"l x 13"w x 12"h / 20 lbs.
- 3x3: 37"l x 13"w x 12"h / 25 lbs.
- 3x4: 37"l x 15"w x 13"h / 32lbs.
- 4x3: 37"l x 15"w x 13"h / 32 lbs.
- 4x4: 36"l x 15"w x 13"h / 35 lbs.
- 5x3: 37"l x 15"w x 13"h / 35 lbs.
- 5x4: 37"l x 18"w x 13"h / 38 lbs.
- 6x3: 36"l x 18"w x 13"h / 43 lbs.


additional information:

- Replacement parts available
- Refer to page 4 for curved Hopup frame footprints
- Refer to page 5 for straight Hopup frame footprints
- Lights & accessories are available
- 4x3 Hopup now packs with a rollerbag into the OCX or OC-HOP case (both optional upgrade)
- 8x3 Hopup now packs into the OCX (optional upgrade)
- 12x3 Hopup now packs into the OCH2 (optional upgrade)


SET-UP:
GRAPHIC COMES ATTACHED




Remove unit from rolling bag. 1




Stretch frame to size. Make sure webbing is not wrapped around purple locking arms. 2




Pull frame outward and align purple locking arms. 3



Snap all purple locking arms into place. 4




Once unit is locked, lift frame into place. *Graphic ships pre-attached to frame 5




Unit is complete 6

TO ATTACH END CAPS



Pull end caps down to corner of frame and attach to Velcro on grey hubs. Repeat for each corner. 7




Repeat on opposite side. 8



Lift frame into place. Unit is complete. 9


ATTACH STABILIZER FEET TO
FRAMES 3 QUADS HIGH



After applying graphic, flip Hopup on its side to access bottom hubs. 1



Start with the largest end of the opening; Slide stabilizer foot over both hubs. Feet will fit snugly over hubs. 2




Move to other hubs on the same side of the frame; slide second foot over hubs. 3




Once finished, flip frame right side up. Unit is complete. 4

TO ATTACH LIGHTS




Slide light onto light base on top of frame. 1


TO COLLAPSE




To collapse unit, first remove end cap graphics on both sides and fold onto top of frame. 1




Unlock all purple locking arms.
*Note: for 5x3 size, release locking arms from outside perimeter frame to the inside. 2



Once all arms are unlocked, slowly push frame inward to collapse. 3



Continue to collapse frame, making sure graphic and webbing do not entangle with purple locking arms. 4



Store unit into rolling bag. Be sure bag straps do not wrap around purple locking arms. 5

to ensure quality, please note:




If the webbing is wrapped around the purple locking arm, the arm can snap off when opening the unit.




When packing unit in the bag, ensure that the strap is not partially wrapped around an arm. If it is, the arm will snap when pulled out of the bag.




Do not use the purple locking arm to lift unit. ALWAYS lift by the frame.




To detach the female arm, remove the screw, steel plate and velcro webbing. Pull the arm off the hub.




Attach the female arm by popping it into the hub. Fasten the screw through the steel plate hole and the velcro webbing tapping into the female arm.



To detach the male arm, pull the arm off the hub.



Simply pop in the male arm into the hub.




Both arms should align to snap lock together.

Hopup Help Guide

Removing a Damaged Locking Arm



1. The unit starts together.



M1. **Unbuckle** the male and female arms then gently tilt either arm up or down.



M2. Loosen the male arm by **wiggling side to side** and remove by pulling to one side.



F1. **Unscrew** the plate and female arm from the frame hub.



F2. Remove the female arm as in M2.; wiggle side to side and **pull out to one side**.

Installing a New Arm



1. Insert the male arm into the frame hub.



2. Insert the female arm into the frame hub.



3. **Line up** the female arm to the frame hub (3A.) and push into place (3B.).



3A. **Make contact** when lining up the female arm and the frame hub for easier connection.



3B. Lock the arm into place by **pushing the two sides** of the frame together.



4. Secure the female arm by **screwing** the plate to the frame hub.



5. The unit is assembled.

Other tips:

- When removing a damaged locking arm, unbuckle nearby arms to relieve tension.
- Drill straight in the middle of the plate when attaching the female arm to ensure security.