


```
+PSPICE
.model Zener30V D(bv=30v)
.include /home/guy/aProjects/circuits/ComponentModels/irfz44n.spi
.include /home/guy/aProjects/circuits/ComponentModels/1n4148.spi
.include /home/guy/aProjects/circuits/ComponentModels/32ctq030.spi
.include /home/guy/aProjects/circuits/ComponentModels/bc547.spi
.include /home/guy/aProjects/circuits/ComponentModels/2n3904.spi
.control
tran 0.1us 15us
*plot i(V1)
plot q1g vsl
plot vpp1 q1d vbb
plot (q1s-vsl)*1000 i(v1)
plot vin*8 q1g q1s vb
.endc
```



Rise time about 1 us

farmerkeith

Sheet: /
File: EnhancedDriver.sch

Title: Enhanced Driver

Size: A4 Date: 2018-06-18
KiCad E.D.A. kicad 4.0.7

Rev:
Id: 1/1