



- ASSEMBLY:
- 1. PLACE PANIC BUTTON(4) ON FRONT HOUSING(2).
 - 2. INSTALL BATTERY CR2025(5) INTO PCBA(1).
 - 3. INSTALL PCBA(1) ON FRONT HOUSING(2).
 - 4. JOIN REAR AND FRONT SUBASSEMBLIES AND UNTRASONICALLY WELD.

5	8002-000-0000	BATTERY CR2025	1	
4	3003-C04-1000	BUTTON, PANIC	1	
3	3002-C04-1000	HOUSING, REAR	1	
2	3001-C04-1000	HOUSING, FRONT	1	
1	1001-C04-1000	PCBA, BUDDY TAG	1	
NO.	PART NUMBER	PART NAME	QTY.	REMARK

		UNLESS OTHERWISE SPECIFIED	NAME		DATE	Le Vise Products LLC. PLANO, TEXAS, USA		
		DIMENSIONS ARE IN MM	DRAWN	Blaine	09/17/13	PART NAME: BUDDY TAG, ASSEMBLY		
		TOLERANCES: ONE PLACE DECIMAL +/-0.05 TWO PLACE DECIMAL +/-0.02 ANGULAR +/-2.0	CHECKED					
		INTERPRETE GEOMETRIC TOLERANCE PER:	EGN APPR.					
		MATERIAL	MFG APPR.					
		FINISH	Q. A.					
		DO NOT SCALE DRAWING	COMMENTS:			SIZE	DWG. NO.	REV.
						A4	1000-C04-1000	A
						SCALE: 1:1	WEIGHT:	SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
P. Q. D. INTERNATIONAL, INC. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
P. Q. D. INTERNATIONAL, INC. IS P
ROHIBITED.

NEXT ASSY USED ON

APPLICATION