

En So many skills in just one tiny sensor. Motion Cookies are seamlessly reprogrammed according to what you want to use them for. You no longer need a specific device for each one of your needs. Cookies are versatile. Change your mind, explore new uses... and stop wasting devices when you don't need them anymore.

En Tous les talents dans un seul petit capteur. Polyvalents, les Motion Cookies se reprogramment au gré de vos envies. Inutile d'avoir un appareil spécialisé pour chaque besoin. Changez d'avis, explorez de nouveaux usages, les Cookies s'adaptent comme par magie.

En Ein kleiner Sensor mit großen Talenten. Die vielseitigen Motion Cookies werden auf Wunsch neu programmiert. Viele Geräte für viele Zwecke sind passé. Entdecken Sie neue Anwendungen: Die Cookies passen sich intuitiv Ihren Stimmungen und Bedürfnissen an.




1

En Make sure you are close to your Mother.
Fr Assurez-vous que vous êtes à proximité de votre Mother.
De Stellen Sie sicher, dass Sie sich in der Nähe Ihrer Mother befinden.

2

En Take a Cookie. Open the colored door by pulling it.
Fr Prenez un Cookie. Détachez la trappe colorée en la tirant.
De Nehmen Sie einen Cookie. Öffnen Sie die farbige Abdeckung, indem Sie sie herausziehen.

3

En Insert a battery. Negative  must face upwards in the Cookie.
Fr Insérez une pile. Le pôle négatif  doit être vers le dessus du Cookie.
De Legen Sie eine Batterie ein. Der Minuspol  muss im Cookie nach oben zeigen.

4

En Close the Cookie door. Keep the Cookie at hand.
Fr Refermez la trappe. Gardez le Cookie à portée de main.
De Schließen Sie die Abdeckung. Halten Sie den Cookie griffbereit.

5

En Log in to your Sen.se account. Click on **More**, then select **Motion Cookie** and follow the instructions.
Fr Connectez vous sur votre compte Sen.se. Cliquez sur **More**, puis sélectionnez **Motion Cookie** et suivez les instructions.
De Melden Sie sich in Ihrem Sen.se-Konto an. Klicken Sie auf **More**, wählen Sie **Motion Cookie** aus und folgen Sie den Anweisungen.

6

En Repeat with the next Cookie.
Fr Recommencez avec le Cookie suivant.
De Wiederholen Sie den Vorgang mit dem nächsten Cookie.



En Having trouble?
Fr Vous avez des difficultés?
De Es ist ein Problem aufgetreten?
+ sensemother.com/help



Certifications

EU Declaration of Conformity
We, Sen.se, hereby declare that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

FCC Caution.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Safety warnings
This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.
Use only with supplied wall power adaptor. The device is intended for indoor use only.
Before inserting the batteries, check that the contacts in the device and on the batteries are clean, and clean them if necessary. Note the polarity (+/-) when inserting the batteries.
Do not throw the batteries into a fire, short-circuit it or dismantle them. Keep children away from batteries. Seek medical attention immediately if a battery is swallowed.

Canadian Compliance Statement
This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference and (2) this device must accept any interference including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.
This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet appareil est conforme aux normes CNR exemptes de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas provoquer d'interférence (2) cet appareil doit accepter toute interférence, y compris celles susceptibles de provoquer un fonctionnement non souhaité de l'appareil. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. Cet appareil et son (ses) antenne(s) ne doit pas être co-localisé ou fonctionner en conjonction avec une autre antenne ou transmetteur.

Legal notice
Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.