




NIBP Board, placement







USB Board, bottom




USB Board, placement




Welch Allyn Board, top




Welch Allyn Board, bottom




Welch Allyn Board, placement




Welch Allyn Board, placement




TruSignal SpO2 Board, top




TruSignal SpO2 Board, bottom




Nellcor SpO2 Board, top




Nellcor SpO2 Board, bottom



Masimo SpO2 Board, top



Masimo SpO2 Board, bottom



TruSignal/Nellcor/Masimo SpO2 Board, placement

