



Installation of your FlexKom POS Terminal

Congratulations to your purchase of your FlexKom POS 4S Terminal!

This document should help you for the initial setup. It contains information about the running time.

In case of open questions, our support will be at your disposal at any time.

E-Mail: support@flexkom.com

Content


1. Buttons
2. Closing of Terminal App with password
3. Auto Update of App
4. Setup of wireless network
5. .Trouble Shooting

1. Buttons

Frontside



Backside




2. Closing of Terminal App with a password


The FlexKom POS Terminal is set to automatically open when switched on. The use of the Terminal will be then in a protected mode to avoid access on the operating system without the valid password.

In case you want to close the Application, mainly to install Wifi, you can do this by leaving the protected mode

- 1.) Push the Home Button in the very low part of the Tablet
- 2.) You will find an input mask, where your password can be put in to leave protected mode (please see the picture on the right hand side)




- 3.) Put the password „aaa“ in the form
- 4.) Confirm it by pushing the „Done“ button
- 5.) To restart the protected mode choose the „FlexKom Terminal“ icon



3. Auto-Update of the Application



Once an update of the app is available, it will be pointed out by pop-up message. You will be prompted to allow the installation. Follow all instructions on the app. After successfully installing the update, the app is going to be restarted.



4. Installing of wireless network


For the use of the POS App, an internet connection is required. To set up the wireless network, please follow those steps:

- 1) Quit the app (see "Exit the terminal app with password").
- 2) From the Home screen, out, start the Settings / Properties App.
- 3) Enable "Wi-fi" (see picture).



4) You see the list of available wireless networks in your area

5) Choose from your own network and verify yourself by typing your wireless password. You should then be connected to your network.



6) Now return by using the Home button to the homescreen. Start the Flexkom Terminal app again.

5. Trouble Shooting

If you have problems with the auto-update, or if the app will not start, there is a recovery version of the app (also by means of icon in the apps listed on the Device).



The opening of Terminal Recovery App enforces installing the latest application, ensuring that the app can be updated in any case.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: FK-POS4S (FCC ID: 2ABTW-FK-POS4S) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at when properly worn on the body is **0.3182W/kg**. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body.

To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.