

TW *Serie I*

8" – 10.1"

Handbuch

Manual

Manuel d'utilisation

Manuale

Manual del Usuario

Guia

Manual

Manuell

Manuell

Käsikirja

Upute

کتاب التعلیمات

راهنما

75720

i.onik®

Important Safety Precautions

- Do not disassemble the product; do not use alcohol, solvent or benzene to clean the surface of the product. Please contact us if you experience any problems.
 - This product should be charged for more than 12 hours when charging it the first three times.
 - Do not store the product in high temperature, humidity or dust; do not put the product in a vehicle with closed windows especially not during summer.
 - Avoid dropping or strong impact to the product, do not shake it violently, otherwise it may cause damage to the touch screen or display.
 - Please select the appropriate volume; the volume should not be too high when using headphones; if you feel signs of tinnitus, please turn down the volume or stop using the product.
 - Please charge the product when:
 - a. The battery icon shows low power.
 - b. The system is automatically shut down. (The system will shut down automatically when the battery is low.)
 - c. There is no response when clicking buttons.
- Note:** Please only use the adapter delivered with the product to charge the tablet. No other chargers can be used – risk of fire!
- Please do not disconnect the machine when it is formatting or uploading/downloading, otherwise a program error may occur.
 - When improperly being shut down, the machine will scan and repair the disk on reboot. This process may take a few minutes.
 - The company is not responsible for memory loss caused by damaging or repairing the product or other reasons stated. Please follow the instructions of this manual when using the tablet.
 - Do not use the product in places where the use of electronic devices is prohibited; e.g. an aircraft
 - Please do not use the product when driving or walking. It may cause an accident.
 - This machine is not water resistant.

Technical specifications


Name	TW Series I 8"	TW Series I 10.1"
Display	8"	10.1"
Resolution	IPS 1280 x 800	IPS 1280 x 800
Casing	Metal	Metal
Chipset	Intel® 3735, Quad Core	Intel® 3735, Quad Core
GPU	Intel® HD Graphic (Gen 7)	Intel® HD Graphic (Gen 7)
RAM	1 GB DDR3/2 GB DDR3*	1 GB DDR3/2 GB DDR3*
Operating System	Windows 8.1	Windows 8.1
Camera	Back: 5 MP Front: 2 MP	Back: 5 MP Front: 2 MP
Wi-Fi	802.11 b/g/n	802.11 b/g/n
Bluetooth	built in	built in
HDMI	built in	built in
Battery	3800 mAh	7800 mAh
Flash Memory	16 GB/32 GB*	16 GB/32 GB*

* Depending on the model


Tablet Overview

Tablet Introduction

This chapter describes the appearance of the tablet, including its buttons and ports; it will guide you to understand the features and accessories.



- (1) Volume +/-
- (2) Power on/off
- (3) Rear Camera
- (4) Micro USB port
- (5) HDMI port
- (6) Earphone jack
- (7) MicroSD card slot
- (8) Microphone
- (9) Speaker



- (1) Speaker
- (2) Rear Camera
- (3) Volume +
- (4) Volume -
- (5) Power on/off
- (6) Earphone jack
- (7) HDMI port
- (8) MicroSD card slot
- (9) Micro USB port
- (10) Microphone
- (11) Power supply

I. Introduction to Desktop

1. Windows 8.1 start image

On the start screen, you can see many programs fixed in the image. These application programs are displayed in the form of "magnet". As long as you click them, you can easily visit them. You need to log on your Microsoft account before the application program completely runs.



2. Image slide applications

Slide downward



In start screen, slide from the top of the screen to view all application programs.

To close the application slide down completely.

3. Introduction to app Interface

Besides the application programs already fixed on the start screen, you can also start other application programs in all application programs, such as other software application programs attached to the Tablet PC.

4. Charm menu column

Slide it to the left from the right side of the screen to start Charm menu column, including: Start, Device, Setup, Share, and Search Program.



Can let you search the files and application programs in the Tablet PC.



Can let you share the program through social exchange website or e-mail.



Can return to the start screen. From the start screen, you can also use this function to return the application program that is opened in the latest.



Can let you read, write and share files, connect external screen or printer with the device connected to the Tablet PC.



Can let you set up the Table PC.

Search menu



Share menu



Device Menu




Set up Menu




II. Basic Operations

1. Dormancy, restart and power off



2. Security Management

User and password setup



Method for quick setup:

Click the "Setup" button in "Charm" setup, and select "Change computer setup". Select "User" on the left and click "Create local account" in "Your account" on the right side. After inputting the password of Complete Windows Live Id Account, input username, password, confirm password and password prompt.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.