

ACCESSORIES

BLUETOOTH

6 GEL CUSHION TIPS

CABLE MANAGEMENT CLIPS

MOBILE CASE + WAIST CLIP

USB CHARGING CABLE

CHARGING

- 1 Locate the Micro USB door and plug in the cable and connect the USB to a computer or AC power source.
- 2 Red light indicates charging and will turn off once battery is fully charged. Full charge is approximately 4 hrs.

BLUETOOTH PAIRING

- 1 When power is off, press and hold for 10+ seconds. Voice prompt "Pairing" followed by blue and red blinking lights indicate Epic is in pairing mode.
- 2 Look for Epic BT in your device settings and connect. If a password is required type in "0000". Voice prompt "Your headset is connected" followed by slow blue blinking light indicates connection.

NOTE: The Epic will automatically pair with the last device connected to when turned on.

QUICK START GUIDE

Bluetooth
PREMIUM WIRELESS EARBUDS
FCC ID:2ACJWJLABEPICBT

BUTTON FUNCTIONS

VOLUME UP:
Click once.

TRACK FORWARD:
Click and hold 2+ seconds.

VOLUME DOWN:
Click once.

TRACK BACKWARD:
Click and hold 2+ seconds.

POWER ON:
Click and hold 3 second.

POWER OFF:
Click and hold 5 seconds.

ANSWER/HANG UP CALLS:
Click once.

BLUETOOTH PAIRING:
See Bluetooth Pairing page

CABLE MANAGEMENT CLIPS

- 1 Create a desired length by looping the cable.
- 2 Secure a cable clip on one end of the loop by pushing in from the top and bottom.
- 3 Secure the second cable clip on the other end of the looped cable.
- 4 Cable clips should be secured to both ends of cable.

FITTING

- 1 Place the earbud housing to your ear while wrapping the memory wire behind the ear.
- 2 Rotate earbud in ear canal and adjust memory wire to your desired fit.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.