

Color Changing LED POD with RF Remote Control

INSTRUCTIONS

INSTALLATION

The RF Remote Control requires two AAA batteries (not included) to be installed.

Install the Color Changing LED POD(s) into the LED Track Light fixture following the instructions for LED POD installation included with the LED Track Light fixture.

OPERATION

A single RF Remote will control multiple Color Changing LED PODs installed in the same LED Track Light fixture.

Note: Multiple Color Changing LED PODs cannot be controlled separately. The RF remote will communicate with all of the Color

Changing LED PODs installed in the fixture the same way.

The RF Remote control has an effective range of 25 feet (7.5 meters). It is recommended to press and hold the buttons on the RF controller down for 1 second for each command to ensure proper RF communication to the Color Changing LED POD(s).

The Color Changing LED POD with RF Remote is designed to allow you to remotely change the color of the light over your aquarium. Once the POD is installed in your Elive Track Light, simply point the RF remote at the light fixture and chose your color. Increase or decrease the color intensity remotely too. A single

RF Remote can control multiple Color Changing LED PODs installed in the same LED Track Light fixture.



TROUBLESHOOTING

If the Remote control is being used to control multiple Color Changing LED PODs installed into a single LED track light, it is possible for the PODs to become out of sync if the RF signal does not reach them all. If this issue occurs please press the desired command on the Remote control again, and the Color Changing LED PODs will re-sync. Alternatively the Reset button can be pressed to return all PODs to white color at 100% intensity. If the issue continues to occur, moving closer to the LED Track light fixture can improve the RF communication to all Color Changing LED PODs installed.

SAVE THESE INSTRUCTIONS

Dist. by/par: Pacific Coast Distributing, Inc.
19601 N. 27th Ave., Phoenix, AZ USA 85027

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.