



FOR QUESTIONS REGARDING
OPERATION OF THIS PRODUCT
PLEASE CALL US TOLL FREE:
1-877-OKK-TOYS
1-877-655-8697

OKK TRADING INC
2721 EAST 45TH STREET
VERNON CA, USA

XCLUSIVE MOTORWORKS™ logos, font style and slogans are exclusive trademarks of OKK Toys and are used under license to XTR TOYS. Ford Motor Company Trademarks and Trade Dress use under license to OKK Toys, www.FordMotorCompany.com. General Motors Trademarks used under license to OKK Toys. While our products are thoroughly safety tested we recommend adult supervision during battery installation. We reserve the right to improve or amend color, product and content specifications.

INSTRUCTION:

- 1) Turn the power switch to the "ON" position located at the bottom of the car.
- 2) Use the controller to move forward and backward clockwise.
- 3) Turn the power switch to "OFF" position after used.
- 4) When the LED light dims on the controller, the batteries are to be replaced.

WARNING: The consumer will take full responsibility and liability for any changes or modifications to this product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: The user is cautioned that changes or modifications not expressly approved by the party.



CAUTION:

- DO NOT USE NEAR OR SUBMERGE VEHICLE OR CONTROLLER IN WATER
- DO NOT MIX OLD AND NEW BATTERIES
- DO NOT LEAVE OLD BATTERIES IN VEHICLE OR CONTROLLER
- DO NOT MIX BATTERY TYPES: ALKALINE, CARBON-ZINC OR RECHARGABLE BATTERIES.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ITEM NO : 21927



OKK Trading, Inc.
2721 E. 45th St.
Vernon, CA 90058
Tel: 323-725-8800
Fax: 323-725-8899

*REQUIRES 6 AA BATTERIES

BATTERIES NOT INCLUDED



CONTROLLER: 2 AA VEHICLE: 4 AA

*REQUIRES 6 AA BATTERIES